

21.7 Overpressure alarm

When this message appears on the display:

- Check whether the level sensor is lying on the bottom of the tank.
- Check the setting of the level sensor. There could be too much water in the tank. If the mechanical float floats up, the system switches off as it produces back pressure.
- In the tank versions, only 1 outlet is usually used and the 2nd outlet is sealed with a blind plug. Overpressure can occur here. Remove the blind plug so that the pressure can escape. Then re-insert the blind plug.
- Use a different outlet if necessary.