

16. Inserting the membrane with adapter sleeve

- Open the membrane housing.
- Remove the membrane from the packaging.
- Lightly grease the two rubber rings on the centre rod of the membrane.
- Place the adapter sleeve on the centre rod and press it evenly over it.



- Then insert the membrane into the housing and press it down.
- You will feel that the adapter ring slips easily into the guide



- Lightly tap the centre rod of the membrane 2-3 times with a hammer
- If the membrane is flush with the housing, the adapter ring is correctly fitted.
- To check, pull out the membrane and look into the membrane housing to see if the adapter ring is flush with the holder in the housing. Check that there are no cracks in the housing.



- Then reinsert the membrane into the housing and screw on the cover.
- The EASYRO has now been converted to the next generation.