

## 23. Preservation

If the EASRO system is disconnected from the electricity and water supply for longer than 1 week, the system must be preserved.

Order preservatives from easymetal.

The preservative is sucked into the system in the same way as it is during maintenance.

The system can then be stored for 6 months.

**Please seal all connections with plugs!**

Remove the pre-filter and allow the filter housing to dry.

Before recommissioning, insert new pre-filters and flush into the drain for at least 3 minutes!

When the system is restarted, the preservative flushes itself out of the system. Note the Microsiemens value on the system. When this value returns to its original value, the system is ready for operation again.