

## 9. Change from tank to pressure control EASYRO 120/240/480

--- You can navigate using the arrow keys ---

- Install the Aquasherriff 8.12 software

Once the software has been installed, one more parameter needs to be set!

Instructions as follows:

- Press the down arrow until the time appears
- Press ESC
- Select "Program" and press OK
- Select "Set Parameter" and press OK
- Go to Block 50 and press OK
- Press OK again, "OFF" appears and flashes
- Press the down arrow key and "ON" appears and flashes
- Confirm with OK
- Press OK several times until the date and time appear on the display again
- Press the up arrow and the start screen appears

The system is now pressure-controlled.

Adjust the switch-on pressure in Set Parameter Block B 69.

Adjust the switch-off pressure in Set Parameter Block B 59 - enter value twice.

The default setting for the system is as follows:

Switch-off pressure 400 = 4 bar ..... Switch-on pressure 280 = 2.8 bar

If these values are adjusted, make sure that there is always a pressure difference of at least 1 bar!